VIOS SOLAR LED WALL LIGHT 6.8W 800LM



SOLTECH SOLTECH offers advanced LED technology that is eco-friendly and utilizes clean energy.

1460 Park Avenue. Emeryville CA 94608 USA

www.soltechlighting.com

Please read and follow all instructions to operate. Save this manual for future reference.

(€ ≰ (°) Ø ∑







SOLTECH LLC reserves the right to update all product data sheets at any time. Consult SOLTECH marketing specialists for publication updates at www.soltechlighting.com

Copyright@2021-2022 SOLTECH LLC, All Rights Reserved.



INTRODUCTION

- 1. This is a solar powered lamp, please install it in a location where it can get enough sunshine.
- 2. Please note the duration of the light depends on sun intake & weather.
- 3. The lamp will automatically turn on at dusk.
- 4. Built-in IC with over-charge, over-discharge, and over-voltage protection.

Warning

- 1. The lamp is equipped with internal batteries. Non-professionals please do not disassemble the lamp.
- 2. Please do not dispose the battery in household garbage to avoid explosion.

CORDLESS



WATERPROOF



BRIGHT







DUSK TO

DOWN SENSOR



MOTION




COST




POWER / LUMEN 6.8W / 800LM **PECIFICATION LED** SMD 2835 X 60PCS LI-ION BATTERY 4.0Ah / 3.7V **SOLAR PANEL** 4.4 Wp, Mono-crystalline Silicon **WORKING MODE** 3 Different Modes **DETECTION ANGLE / AREA** 120° ≤ 19.7ft **VISIBLE DISTANCE** 39.3 ft **IP DEGREE** IP65 WARRANTY 3 YEARS **LIFESPAN** 35,000 hrs **INSTALLATION HEIGHT** < 13.1 ft Solar Light X 1, Accessory Bag X 1, **PACKING** User Manual X 1, Measure Card X1


3 INSTALLATION






- 2. Fix 3 expansion plugs into the holes
- 3. Fix 3 screws into the expansion plugs leaving spare space to hang & secure the light.
- 4. Hang the notch onto the screws and fasten the lamp
- 5. Press the power button on the back to program the operating mode









OPERATING MODES

Please press the power button to program an operating mode:

Press 1 time for **MODE A**Press 2 times for **MODE B**Press 3 times for **MODE C**

Press 4 times to TURN OFF


MODE A

Automatically turn on at dusk (< 30 Lux) and remains at 20% brightness for 5 hours then turns off.



MODE B

Automatically turns on to full brightness (800LM) when motion is detected in the range \$19.7ft and then dims to 3% brightness in 20 seconds of no motion.



MODE C

Automatically turns on to full brightness (800LM) when motion is detected in the range ≤19.7ft and then turns off in 30 seconds of no motion.

